

## Tools and Materials Needed for Assembly:

- Staple Gun with ½" staples
- Drill
- Hammer and Mallet
- Wood Glue (optional)
- Bar Clamp
- Marking Jig
- Knife
- Pencil



## Instructions:

1. Lay the face frame face down.
2. Apply glue (optional) to the backside of the triangle support strips and place to the left and right side of face frame, then staple at a 45-degree angle to secure to the face frame.
3. Apply glue (optional) to the edge of the triangle support strips at the face frame.
4. Take the front side panels, and line them up with the face frame dado and secure using the assembly blocks by placing a pair of staples into each leg of the block.
5. Apply glue (optional) to the face frame dado and insert the bottom of the cabinet, then clamp the sides to the bottom. Staple at a 45-degree angle on the bottom and onto the sides, then repeat for the top.
6. Apply glue (optional) to the top and bottom dados of the rear side panels, clamp the front and rear side panels together. Staple at a 45-degree angle where the back and side panels meet, then using the assembly blocks secure the back to the sides.
7. Draw a line on the back of the cabinet with a jig, then screw the back to the top and bottom.
8. Insert the diagonal back into the groove and screw into place, then attach the four hanging strips to the rear side panels of the cabinet with screws.
9. Insert shelf clips into the holes on the backs and sides and insert the shelves.
10. Attach the hinges to the door and then attach the door to the face frame.