

## Tools and Materials Needed for Assembly:

- Staple Gun with ½" staples
- Drill
- Hammer and Mallet
- Wood Glue (optional)
- Bar Clamp
- Marking Jig
- Knife
- Pencil



## Instructions:

1. Lay the face frame face down and apply glue (optional) to the face frame dado. Insert the cabinet sides into the dado, then secure using the assembly blocks by placing a pair of staples into each leg of the block.
2. Glue (optional) and insert the cabinet bottom and top into the dados. Then staple the bottom and top at a 45 degree angle into ONLY one side. Using the assembly blocks, secure the bottom and top to the face frame and the one side.
3. Apply glue (optional) to the cabinet back dados and insert the cabinet back. Screw the back of the cabinet using the pocket screws.
4. Staple the side that was left loose in step 2.
5. Using a jig, mark the cabinet back. Then screw the back to the top and bottom.
6. Staple at a 45 degree angle the back to the side panels.
7. Insert shelf clips into the holes on the sides and insert the shelves.